



Granite Mailbox Post Installation

Step One	Start by choosing the type and finish of the granite you want. A standard post is 7" x 7" x 7' tall. Posts are fabricated from Salt & Pepper, Barre, or Caledonia granite and can have a split face or rock face finish. Speak with your sales representative about the many different options available.
-----------------	---

Always contact Dig Safe (888-dig-safe) before starting any excavation project.

Step Two	Contact your local post office to determine the exact measurements required for mail delivery. Generally the bottom of the mailbox needs to be between 40"- 44" from the ground.
-----------------	--

Step Three	Depending on whether you have a curb or not, the excavated hole will be between 27" – 33" deep and 18" wide. Tamp down the existing material in the hole and check for proper depth.
-------------------	--

Step Four	Lower the granite post into the hole making sure the post is level and square to the road. Backfill the hole with $\frac{3}{4}$ " crushed gravel and compact in 4" – 6" lifts. A concrete fill is not recommended as posts tend to snap beneath ground level if hit by a vehicle.
------------------	---

Step Five	Adding a mailbox to the top of the bracket will finish the installation. Granite mailbox posts are an easy, inexpensive, and classic way to add curbside appeal to your landscape.
------------------	--

If you have any questions, call or stop by either of our two locations.

603-749-9797 or 603-431-0088